



MAGNETICS

AUTOMATIC EQUIPMENT CORPORATION
4699 INTERSTATE DR, CINCINNATI, OHIO 45246
PHONE: (800) 635-3954 FAX: (800) 635-3955

E-MAIL: aec@aecmagnetics.com ON-LINE: www.aecmagnetics.com

MAGNETIC SPECIALISTS FOR AUTOMATED MANUFACTURING

PERMANENT MAGNETIC SHEET HANDLER

SH-250

LENGTH	WIDTH	DEPTH	WEIGHT	MIN TEST	MAX WORK
6"	6"	1-3/8"	6-3/4"lbs.	250 lbs.	125 lbs.

REPLACEMENT PARTS:

H-783-A HANDLE
H-420-S PIN
H-419-M SPRING



INSTRUCTIONS

1. Clean work surface, before applying the Sheet Handler. Dirt, slag, rust or even oil will reduce the effectiveness and lifting capacity of this tool.
2. To release magnet push handle forward as indicated by the arrow on the magnet.
3. After use, clean face of Sheet Handler with a shop towel or air nozzle to remove chips or dirt.
4. Store in a clean place between lifting operations.

CARE

1. Avoid using Sheet Handler for any operation other than lifting or pulling steel parts.
2. Keep working face clean.
3. **DO NOT** bang or slam the tool against work.

REPAIR

When the active face of the Sheet Handler becomes worn or parts need replacing, please contact our customer service department at (800) 635-3954, before shipping Sheet Handler in for repair.