

## INSTALLATION:

Use threaded holes in the back of electromagnet to mount.

Apply 24 Volts DC to leads. Polarity is unimportant as electromagnets work equally well in forward or reverse polarity.

## MAINTENANCE INSTRUCTIONS:

Electromagnets require very little maintenance to provide a long useful life. Daily use of a shop towel to wipe the face of the magnet free of debris, grease and oil or other foreign matter will ensure years of service life and thousands of safe lifts.



# MAGNETICS

AUTOMATIC EQUIPMENT CORPORATION  
4699 INTERSTATE DR, CINCINNATI, OHIO 45246  
PHONE: (800) 635-3954 FAX: (800) 635-3955

E-MAIL: [aec@aecmagnetics.com](mailto:aec@aecmagnetics.com) ON-LINE: [www.aecmagnetics.com](http://www.aecmagnetics.com)

**MAGNETIC SPECIALISTS FOR AUTOMATED MANUFACTURING**


MODEL# CE-075-24C

INPUT: 24VDC

CURRENT: 4.8 WATTS

DUTY CYCLE: CONTINUOUS

HOLDING POWER: 9 LBS.



IF YOU HAVE ANY QUESTIONS ABOUT THIS MAGNET OR THE CORRESPONDING DC POWER SUPPLY, PLEASE CALL OUR ENGINEERING DEPARTMENT FOR ASSISTANCE: (1-800-635-3954)

AUTOMATIC EQUIPMENT CORP  
CE-075-24C  
CUST. DWG.  
SCALE: 1" = 1/2" 2/17/20  
H-12009